



OWNERS MANUAL

Intended for Residential Use Only – meaning private homes.

Swing components etc. that are used for Adventure World Gymsets are intended for use by children under the age of 13 with a weight under 125 lbs per individual. Slide and swing component products are intended for use by children with adult supervision. A level site is recommended for appearance and safety of your product.

Maintenance: Replace any broken or missing parts before next use. Clean with garden hose and/or glass cleaner. Keep area free from trees, wires, fence, obstacles, insects or rodents.

Contact your local dealer for any repair issues.

DO NOT:

- Leave children unattended when playing on gym set
- Paint, caulk, or varnish your gym set
- Use play set if any pieces are missing or broken
- Strike or hit any vinyl or plastic with a hard object which may cause damage to the product
- Use power equipment close to any parts of play set which may cause an object to fly and hit a play set component
- Allow children to play on or near before installation is complete

DO: Hug your children everyday and remember to supervise them when they play!

Please complete your product registration form below – **RETAIN THIS COPY FOR YOUR RECORDS** You will need to keep this information in a safe place. Should you have a warranty claim please contact your local dealer where you purchased the set and they will assist you with the process. Please fill out one at end of Owner's Manual and return to us to activate registration

ADVENTURE WORLD GYMSETS	Date of Purchase _____
Customer Name _____	Phone: _____
Address: _____	
Dealer Name _____	
Dealer Location _____	Phone: _____
FOR OFFICE USE ONLY:	
Serial# : _____	Package # _____ Color: _____
Installed _____	By: _____

Consumer Warranty

Offering Peace of Mind

Adventure World Gymsets (AWG) warrants to the original owner at the original installation address, a Limited 20 Year Warranty that covers defects in workmanship and materials that affect the structural integrity of the playground systems, such as the PVC plastic lumber and wood components. In addition slides, swings and accessories are covered by a Limited 5 Year Warranty from date of original purchase. Powder coated parts, chains, surface rust, corrosions or color fading which do not affect the structural integrity of the product, are not considered defects in workmanship or material, and are not covered by this warranty. Painting, varnishing or administration of any other material to the AWG system voids the warranty of the product. In the event of a defective piece, AWG will repair or replace at its discretion any defective piece unless it is not practical; then AWG will reimburse the original owner for the value of the defective piece. AWG may require the original owner to ship the defective part(s) to AWG for inspection and determination of warranty coverage. The cost of freight for the replacement product and any others costs associated such as labor to replace the new product are not covered under the Warranty.

These Limited 20 Year and Limited 5 Year warranties are limited to products used for residential, single family dwellings and subject to ordinary use and proper installation. Any play set installed other than residential, single family dwelling will have a limited warranty to 10 years. The warranty and registration card must be filled out and returned within 20 days of installation for the warranty to be in effect. Installation or repairs by unauthorized persons are not covered under the warranty. Acts of God are not warranted.

AWG is continuously striving to improve our play set design and reserve the right to change design and/or components without notice.

Adult supervision is recommended when enjoying your Adventure World Gymsets.

AWG home playground equipment, also called residential playground equipment is for use in a private backyard in a properly designed, constructed, installed, and supervised playground setting.

A WORD OF CAUTION: Children should not use the equipment until proper installation is complete.

OPERATING INSTRUCTIONS:

Please observe the following statements and warnings and reduce the likelihood of serious or fatal injury.

- This equipment is for use by children only, between the ages of 18 months and 12 years of age and under 125 pounds.
- Children must always be supervised by an adult.
- Dress children appropriately with well fitted shoes, and clothing. Avoid ponchos, scarf's and other loose fitting clothing that is potentially hazardous while using the swing set.
- Children should not be allowed to climb on the swing set while it is wet.
- Bike helmets and other sports equipment should be removed before using the swing set.
- Swings, chains, or ropes or any part of the gym set should not be twisted or looped over the top swing support bar.
- Instruct children to avoid swinging empty seats.
- Children should be warned to not walk in front or in back of the swings while they are being used.
- Children should be instructed to not get off equipment while it is moving.
- Children should sit in the center of swing seats with their full weight on the seats.
- Do not allow children or anyone else to use the equipment in a manner for other than what it is intended.
- Make sure the suspended climbing ropes are secured at both ends.
- Verify that suspended climbing ropes or chain cannot be looped back on itself.
- Children should never attach items to the swing set equipment that are not specifically designed for use with the equipment, such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard.

MAINTENANCE INSTRUCTIONS:

At the beginning of each play season:

- Tighten all hardware.
- Lubricate all metallic moving parts monthly during play season.
- Check all moving parts including swing seats, ropes and chains for wear, rust, or other deterioration. Replace as needed.
- Check metal parts for rust. If found, sand and repaint using a non lead-based paint. Avoid getting paint on vinyl or plastic parts.
- Reinstall any plastic parts, such as swing seats or any other items that were removed for the winter months.
- Rate and check depth of loose fill protective surface materials to prevent compaction and to maintain appropriate depth. Replace as necessary.

Twice a month during play season:

- Tighten all hardware.
- Check all protective covering on bolts, pipes, edges and corners. Replace if there are loose, cracked or missing.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth.. Replace as necessary.

Once a month during play season:

- Lubricate all metallic moving parts per manufacturer's instructions.
- Check all moving parts including swing seats, ropes and chains for wear, rust or other deterioration. Replace as needed.

At the end of each play season or when the temperature drops below 20 degrees F

- Remove plastic swing seats and other items as specified by the manufacturer and take indoors or do not use.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth.. Replace as necessary.

KEEP THIS INFORMATION IN A SAFE PLACE. YOU WILL NEED THIS INFORMATION IN THE EVENT OF A WARRANTY CLAIM. THE ORIGINAL OWNER MUST RETURN THE ATTACHED PRODUCT REGISTRATION CARD WITHIN 20 DAYS OF PURCHASE FOR THIS WARRANTY TO BE IN EFFECT. WARRANTY CLAIMS WILL NOT BE HONORED IF THE ORIGINAL OWNER FAILS TO RETURN THE CARD WITHIN 20 DAYS OF PURCHASE.



OWNERS MANUAL

Product Registration Card – Please fill out this copy and return within 20 days of purchase to activate.

ADVENTURE WORLD GYMSETS	Date of Purchase _____
Customer Name _____	Phone: _____
Address: _____	
Dealer Name _____	
Dealer Location _____	Phone: _____
Was this gym set installed at a Single Family Dwelling? <input type="checkbox"/> Yes <input type="checkbox"/> No	
Was the gym set properly installed by a qualified professional? <input type="checkbox"/> Yes <input type="checkbox"/> No	
FOR OFFICE USE ONLY:	
Serial#: _____	Package # _____ Color: _____

PLEASE RETURN TO

ADVENTURE WORLD GYMSETS
388 MILLCREEK ROAD
BIRD IN HAND, PA 17505